
Südweg 1 | 36396 Steinau-Ulmbach | Tel. +49 6667-918 47-0 | Fax +49 6667-918 47-27 www.eurotronic.org | info@eurotronic.org



# User manual Stella Z

#### description



- 1 Stella Z
- 1 User manual
- 1 Connector
- 3 Adapters (Danfoss RA, RAV, RAVL)
- 1 Too

## Inserting/replacing batteries

- 1. open the battery case
- 2. insert batteries
- 3. close the battery case


Only at the first installation, the Stella Z drives into mounting position. It stays at this position, until the button was pressed.

### Montage

Stella Z can be quickly and easily mounted on all common valves. It can be installed without grime and water spots because the heating circuit is not interrupted.

- 1. Use an appropriate adapter, if required, and push it onto the valve.
- 2. Screw the connector on the valve or the adapter.
- 3. Now, you put Stella Z on the connector until it noticeably clicks into place.

valve - [adapter] - coupling ring - Stella Z



Never turn Stella Z on the coupling ring!

# **Initial Commissioning (adaption)**

After the batteries were inserted, the ram drives back and stays in the mounting position. Press the button after the mounting. Now Stella Z adapt and after the adaption it stays in the closed valve.



#### LEDs:

- **OK** Green (2 sek.) (Learn completed, NIF sent, Wakeup sent,...)
- Failed Red (2 sek.)
  (Learn mode failed or NIF/Wakeup Notif send failed)
- NWI Red-Green blink (only in NWI mode)
- Install Green blink (Installation mode)
- Error Red blink (Error communicating)

### **Learning in of the radio partner:**

- 1. Set the partner (Postmaster) into the learning mode.
- 2. Push the button on Stella Z with the supplied tool for at least 10 seconds.
- Z-Wave-Station gives a signal, when Stella Z is connected.

### **Adapters**

Heimeier, Junkers Landys+Gyr, MNG, Honeywell, Braukmann thread- measure dimension of M 30x1,5	no adapter required
Danfoss RAV (beiliegender Pin muss auf Ventilstößel gesteckt werden)	+ accompanying pin, only for RAV!
Danfoss RA	
Danfoss RAVL	

### **Dismounting**



- 1. Insert both tips of the supplied tool (1) into the opening.
- 2. Remove Stella Z from the adapter/valve.